

These instructions describe and illustrate the steps involved in installing CertainTeed siding and trim. Their purpose is to provide detailed information and how-to tips that will simplify the installation process. CertainTeed shall not accept any liability or responsibility under its written warranty for failure caused by application that does not meet our minimum requirements for proper installation. These requirements are outlined throughout the *CertainTeed Installation Guide (CTS205)*. Any deviations from these requirements should be approved in writing by CertainTeed Corporation.

Corner Block

Install a 1/2" J-channel as a starter strip. Measure and cut the side lineals to the exact size of the window or door opening. Cut the top and bottom lineals 1/4" longer than the window.

Using vinyl snips, make two 1" long cuts in the pocket areas on both sides of each lineal. These cuts allow the lineals to connect with the corner block and help provide proper drainage.

NOTE: *It may be helpful to hold off securing the lineals until the corner block is in place.*

Position the corner block by inserting the top lineal into the corner block's receiving area – making sure the lineal's pocket is inside that of the corner block.

Position the vertical (side) lineal into the corner block by inserting the pocket of the corner cover into the pocket of the lineal. This will ensure proper drainage.

Corner Block with Rosette

Locate the small dimple on the back side of the block's face or measure 2-5/16" as shown and mark.

Drill or punch a 3/32" - 1/8" diameter hole through the face of the block – the hole must not be larger than 1/8".

NOTE: *Check the back side of the block for this location – marked by "+"*

Apply the rosette clip from the backside. If desired, a small amount of caulk can be applied over the hole prior to applying the rosette.

If you have any questions about installing this product, please call us at 800-233-8990.

