



Notes:

1. Install lead roof jack with 4" wide primed continuous flange on top of built up roofing ply sheets.
2. Sheet metal sleeve flanges must also be nailed 3" o.c., $\frac{3}{4}$ " in from perimeter edge.
3. For granulated torch-welded systems, prepare surface to receive Flintlastic flashing collar by heating and removing or sinking granules.

CertainTeed
 SAINT-GOBAIN
Commercial Roofing

ISSUE DATE	REVISION	DRAWING NUMBER
10/11/2013	B	CT-12
SCALE		
Not to Scale		Sheet 1 of 1