

TECHNICAL MEMO

RE: Maintenance Instructions for Symphony[®] f acoustic ceiling panels	
From: CertainTeed Ceilings Technical Services	Phone: 800-233-8990
Email: ceilingtechnicalservices@certainteed.com	

Handling

Clean cotton gloves should be worn at all times, both during the initial ceiling assembly and any subsequent activity that may require a panel to be removed. When panels are removed they should be taken completely out of the grid and stored on a flat surface. Panels should be laid face to face in order to prevent unnecessary soiling and damage during their temporary displacement.

Cleaning

Clean panel by using a sponge or cloth dampened with a water and mild liquid detergent solution (*such as Dawn Ultra[®] dish soap*). Squeeze the saturated sponge or cloth until it is merely damp. Then lightly wipe the surface to be cleaned. Do not moisten panel excessively. Never soak panels with water.

**If any portion of this information provokes a question, please contact
CertainTeed Ceilings Technical Services.**