

| | | | |
|-----------------|---|-------------|--------------|
| Subject: | Maintenance Instructions for CertainTeed fabric-faced fiberglass panels (Akusto Wall Panel C – Texona, Akusto One, Data Center Black, Open Plan Nubby, Theatre Black f) | | |
| Date: | June 12, 2025 | Tel: | 800-233-8990 |
| Email: | Robert.L.Marshall@saint-gobain.com Thomas.Callahan@saint-gobain.com | | |

Handling

Clean cotton gloves should be worn at all times, both during the initial ceiling assembly and any subsequent activity that may require a panel to be removed. When panels are removed, they should be taken completely out of the grid or frame and stored on a flat surface. Panels should be laid face to face to prevent unnecessary soiling and damage during their temporary displacement.

Cleaning

Panels can be cleaned of dust and loose dirt particles with a dry, soft, micro-fiber cloth. Panels can also be cleaned by vacuuming with a soft brush attachment.

If any portion of this information provokes a question, please do not hesitate to contact CertainTeed Technical Services.