

Vinyl Gates

Assembly Instructions




Table of Contents

General Information	2
Tools Required	2
Double Drive Gates	2
Before You Begin	3
Assembly Instructions.....	3-6
Section 1: Gate Assembly.....	3
Assemble Gate.....	3-4
Section 2: Installing Gate.....	5
Position Gate	5
Install Hinges.....	5
Install Latch.....	5
Aluminum Insert.....	5
Rebar and Concrete.....	6
Railing Gates.....	6
Screw Templates.....	7-9
Anatomy of a Gate Hinge and Latch Post.....	10

General Information

Please read these instructions thoroughly before beginning the assembly.

- Use extreme care when applying PVC cement as it dries quickly.
- During assembly, lay PVC components on a non-abrasive surface (such as a drop cloth) to avoid scratching.
- Clean PVC with a mild detergent and plastic scouring pad.
- Assemble PVC components without using excessive force to avoid breakage.
- Aluminum framed gate may be racked if needed.
- Gate must be assembled prior to fence to accurately locate hinge and latch post.
- Gate horizontal rails will line up with fence horizontal rails.
- Gate requires 2" clearance under bottom rail on level ground.
- Gate hardware requires 1" gap for hinge and 3/4" gap for latch.
- Gate hardware must be mounted on two sides of post.
- INSTALLING RAILING GATES: Post should be reinforced with post support kit or sleeved over wood post.


Tools Required

- Measuring tape
- Phillips #2 screwdriver
- Large slot-head screwdriver (to activate spring in hinge)
- Saw with masonry blade
- Drop cloth
- Electric or cordless drill (use low clutch settings)
- Various drill bits (1/8", 3/16", 1/4", 5/32")
- Rubber mallet
- Leveling blocks
- Level
- 7/16" wrench
- Square
- Pencil
- File
- #3 square drive bit

Double Drive Gates


For aluminum frame gates, order two standard gates (does not have opposite gate).

- Double drive gates require a drop pin kit.
- Allow a space of 2-3/4" between the hinge posts when determining the size of each gate.



Before You Begin

Determine Width of Gate



- Width of gate will be determined by length of horizontal rails.
- Rails must bottom out inside uprights.
- Cut rails to achieve equal picket spacing. Measure out from center of hole cut-out or center of picket spacing.
- Single gates should be made 1-3/4" smaller than the gate opening to allow for hardware.
- Double drive gates require an allowance of 2-3/4" between hinge posts for hardware and drop pin kit.
- When cutting rails, be certain to drill 1/4" holes in bottom rails for water drainage.

Section 1: Gate Assembly


The Vinyl Gate Kit is designed to build one (1) vinyl gate at the width of the standard walk gate. Extension kits are available for certain styles. Refer to product catalog for offering and maximum width.

Box Contains:


- Vinyl Gate Uprights with Aluminum "U" Channel Inserts
- Aluminum Channel Rail Inserts
- Hardware Bag
- Upright Caps

NOTE: Vinyl rails, pickets and hardware sold separately for fence gates. Railing gates include vinyl rails, vinyl balusters and gate hardware.


- Remove steel channel from fence rails if previously inserted (fig. 1).
- Cut rails to length - cut rail 1/2" shorter than desired final gate width.
- Insert aluminum channel into rails.
 - Aluminum will also need to be cut to match vinyl rail length (fig. 2).
 - For fence styles with ribbed rails, insert channel in center chamber of rail.
- Drill 1/4" holes in bottom rail for water drainage.
- For privacy gates:
 - Attach vinyl end channel to gate uprights with 4 screws per side.
 - Insert top & bottom rails into one of the gate uprights (fig. 3).
 - Slide pickets into rails. For shorter width gates, picket will need to be ripped.
 - Slide second gate upright over rails (fig. 4).



(fig. 1)



(fig. 2)



(fig. 3)




(fig. 4)

- For all other standard gates:
 - Insert pickets/balusters into rails.
 - (For railing gates, refer to the chart to the right for vinyl baluster lengths.)
 - Insert rails into one of the uprights.
 - Slide second gate upright over rails.


Oxford*	Kingston
3' high = 33-1/4"	3' high = 31-1/4"
3-1/2' high = 39-1/4"	3-1/2' high = 37-1/4"

*does not require cutting


- Ensure rails are inserted all the way into upright and pickets are flush against uprights (fig. 5).
- Check overall width of gate to ensure it meets desired target (fig. 6).
- Square gate by measuring diagonally from one upright to the other in both directions (fig. 7).
- Drill holes and insert 2 screws in each corner of the gate. (Use templates in the back of these instructions for screw placement. See box below for additional information). Screws should be inserted through rail to ensure connection with aluminum channel inside rail (fig. 8a and fig. 8b).
- Flip over the gate assembly and repeat screw insertion for each corner.
- Attach gate upright caps with silicone caulk or PVC cement (fig. 9).




(fig. 5)




(fig. 6)



(fig. 7)



(fig. 8a)



(fig. 8b)



(fig. 9)

Use the templates in the back of these instructions for proper screw placement.


- Screw templates for 2x6 Ribbed and 2x6 Privacy Rails — see page 7
- Screw templates for 2x3-1/2, 2x4 and 1-1/2x5-1/2 Deco Rails — see page 8
- Screw template for Kingston Rails - see page 9



Section 2: Installing Gate

1. Position Gate / Locate Hinge

- Position gate between fence posts. Allow 1" gap on hinge side and 3/4" gap on latch side of the assembled gate for hardware and gate swing.
- Use leveling blocks under gate to square gate with fence posts. Fence and gate horizontal rails should be level.
- Gate hardware must be mounted on two sides of post.
- Locate hinge position on gate upright and hinge post. Top of top hinge is in line with bottom of top rail. Bottom of bottom hinge is in line with top of bottom rail.
- Hinges should be installed as far apart as is practical, for optimal performance.
- To mount the hinges, drill 5/32" pilot holes to accept screws when using aluminum post inserts.



2. Install Hinges

Installation may vary based on gate hardware kit ordered. Refer to manufacturer's recommended installation instructions.

- Works with both left-hand and right-hand gates.
- Hinges must be mounted on two sides of the post.

3. Install Latch

Installation may vary based on gate hardware kit ordered. Refer to latch installation instructions included with your gate hardware for exact instructions.

4. Installation Instructions When Using Aluminum Insert

Optional Post Support

Designed for use in end, hinge and latch post

Installing insert into post (insert into post before setting post)*

Drive a screw through the vinyl into the aluminum in the bottom of post. This will prevent the insert from moving inside the post.


Routed Post

Insert aluminum into post with open end facing routed hole.




Blank Post

Make sure that you set your post so that you will be attaching the hinge plate to the aluminum in both directions.



Attaching Hinge Plate


To attach hinge plate to post with insert, pre-drill a 5/32" pilot hole for screws.



*NOTE: Insert will not work in corner, line or 3-way posts.
Refer to rebar separator clip instructions if not using aluminum insert.

5. Installation Instructions When Using Rebar and Concrete in Posts**

- Connect two pieces of 1/2" rebar together with rebar separator clips. Length of rebar should extend from bottom of hole to 12" from top of post.
- Insert rebar in opposing corners of all hinge, latch and end posts.
- The use and placement of rebar is critical for the strength and quality of the fence installation.
- Fill fence posts with concrete mix to cover rebar and gate hardware fasteners.
- Tamp out any air pockets with a rubber mallet.
- Leave gate on blocks for concrete to set up. Remove blocks after 72 hours.



*** Caution - In climates that experience freeze-thaw cycles, this installation method could result in post cracking. This would not be covered by the warranty.*

6. Railing Gates

Post should be reinforced with post support kit or sleeved over a wood post.

Screw templates for 2x6 Ribbed and 2x6 Privacy Rails

CUT

FOLD

2x6 Privacy

Chesterfield
Galveston
Brookline

USE ON TOP LEFT & BOTTOM RIGHT OF GATE
USE ON TOP RIGHT & BOTTOM LEFT OF GATE

FOLD

CUT

CUT

FOLD

CUT

FOLD

2x6 Ribbed

Breezewood
Millbrook
Manchester



USE ON TOP LEFT & BOTTOM RIGHT OF GATE
USE ON TOP RIGHT & BOTTOM LEFT OF GATE

FOLD




CUT

CUT

FOLD




Screw template for Kingston Rails



Notes:

Notes:

Anatomy of a Gate Hinge and Latch Post



CertainTeed

CEILINGS • DECKING • FENCE • GYPSUM • INSULATION • RAILING • ROOFING • SIDING • TRIM
 20 Moores Road, Malvern, PA 19355 Professional: 800-233-8990 Consumer: 800-782-8777 certainteeted.com