

Anchor Sheet

Attach with appropriate fasteners spaced a minimum 9" o.c. in the laps with two additional rows spaced 18" o.c. in the field, staggered OR as required by code.

Fasten starting fasteners 6" in from the edge of the roof to avoid edge metal fastener overlap.

Flashing Collar


Fully adhere (self-adhered, torch, cold process or hot asphalt). **If self-adhered** apply FlintBond® Caulk to edge; **If torch-welded** ensure 1/4" bleed out at edge; **If using cold process** set in FlintBond Trowel with 1/4" bleed out at edge; **if using hot asphalt** ensure 1/4" bleed out at edge.

Edge Metal

Mechanically attach a minimum two staggered rows, 6" o.c. or as required by building code; endlaps should receive two nails. Edge Metal shall have a minimum 3/4" rise for gravel surfaced membranes and a 3/8" rise for smooth or mineral surfaced membranes.

Cap Sheet

Fully adhere (self-adhered, torch, cold process or hot asphalt). **If self-adhered**, in cold weather¹ where Flintlastic® SA Cap (FR) Sheet overlaps Edge Metal surface, hot air weld² with bead of FlintBond Caulk at edge.



NOT DRAWN TO SCALE

¹20°F-49°F (-6.6°C-4.4°C)

²Apply heat from a hot-air welder with a 2" tip to the overlapped granular surface while applying rolling pressure from a silicone roller to the overlapping Cap. With the hot air welder set between 900°F-1,100°F (setting 8-10), apply heat to the overlap interface while bonding Cap with rolling pressure on the granulated surface. Roll the overlapping Cap in place, moving the hot air welder to allow for forward progress. Avoid applying so much heat or moving at a pace that results in smoke. Apply a bead of FlintBond Caulk along the edge. Continue overlap application, 2" per pass.